

## Operator REST\_MODE\_NONL

---

### 1 Goal

---

The operator `REST_MODE_NONL` allows to restore in the temporal field or the field of Fourier a periodic solution resulting from a calculation with `MODE_NON_LINE`.

This operator produces a concept of the type `dyna_trans` (in the temporal field) or `mode_meca` (in the field of Fourier).

## Contents

---

1 Goal.....	1
2 Syntax.....	3
3 Operands.....	4
3.1 Keyword MODE_NON_LINE.....	4
3.2 Keyword NUME_ORDRE.....	4
3.3 Keyword TYPE_RESU.....	4
3.4 Keyword NB_INST.....	4

## 2 Syntax

---

```
resu_out = REST_MODE_NONL (
  ♦ MODE_NON_LINE = resu_in, [table_container]
  ♦ NUME_ORDRE = /num_ordr, [I]
  ◇ TYPE_RESU = /'DYNA_TRANS', [DEFECT]
                /'MODE_MECA'
# If keywords TYPE_RESU = 'DYNA_TRANS':
  ◇ NB_INST = /512, [DEFECT]
                /nbinst, [R]
)
```

## 3 Operands

---

### 3.1 Keyword **MODE\_NON\_LINE**

◆ MODE\_NON\_LINE

resu\_in Concept of the type table\_container exit of a calculation with the operator MODE\_NON\_LINE.

### 3.2 Keyword **NUME\_ORDRE**

◆ NUME\_ORDRE

num\_ordr indicate the sequence number of the periodic solution resulting from resu\_in that one wishes to restore.

### 3.3 Keyword **TYPE\_RESU**

◆ TYPE\_RESU

If TYPE\_RESU = 'MODE\_MECA' then resu\_out is a periodic solution in the field of Fourier.  
If TYPE\_RESU = 'DYNA\_TRANS' then resu\_out is a periodic solution in the temporal field.  
By default, TYPE\_RESU = 'DYNA\_TRANS' .

### 3.4 Keyword **NB\_INST**

◆ NB\_INST

nb\_inst is the desired discretization of the periodic solution, for a restitution in the temporal field (i.e. TYPE\_RESU = 'DYNA\_TRANS'). It should be noted that nb\_inst must be a power of 2. By default, nb\_inst = 512.